

Release Notes

V3.0.59

Bug fixes:

- Overexposure with a low probability during taking pictures

V3.0.58

Bug fixes:

- Resolve the issue that the camera shows a “white screen” when it turns on at very low probability.

Others:

- Typographic modification on MENU > Version

V3.0.53

New features:

- Added an option "Delete All" for removing all of photos and videos when reviewing photos or videos on the camera (*Tip: When camera is powered on, here is the way to get the option: press OK to review photos, then press RIGHT button, there are 2 options - Delete current one and Delete all*)
- “Operation Hours” supports AM/PM format

Bug fixes:

- Corrupt files those might cause freeze when reviewing photos on camera, or those aren't viewable on computer. Please format your SD card to remove the corrupt files after firmware is upgraded.
- SD card is unrecognized. If it is, please format your SD card firstly per the doc from link: <https://www.zopudt.com/wp-content/uploads/2021/09/How-to-fix-SD-card-issues-v1.pdf> , then upgrade your camera.

- Abnormal playback on iMovie on Mac computer, or on Windows Media Player
- Eliminate: pitch when night recording, screen flickers
- Other minor changes for more stability
- Reduction of false trigger